

Deltec Sine Wave controller error codes

ERROR	FLASH CODES	ACTION
<p align="center">PUMP RUNNING DRY</p>		<p align="center">CHECK PUMP IS SUBMERGED</p>
<p align="center">PUMP NOT WORKING</p>		<p align="center">CHECK PUMP IMPELLER FOR FOREIGN OBJECTS OR CALCIUM BUILD UP – CLEAN PUMP IN EZE-CLEAN SOLUTION</p>
<p align="center">CONTROLLER OVERHEAT</p>		<p align="center">CHECK THAT THE CONTROLLER HAS FREE FLOW OF AIR AROUND IT AND CLEAN PUMP</p>
<p align="center">ABNORMAL VOLTAGE</p>		<p align="center">CHECK ELECTRICAL CONNECTIONS AND POWER SUPPLY</p>
<p align="center">CONTROLLER CURRENT ABNORMAL</p>		<p align="center">CHECK ELECTRICAL CONNECTIONS AND POWER SUPPLY</p>